



P/N: 70-13-1M00-015 (REV. C)

Description: SMB Right Angle Male Crimp for LMR100/RG174/RG316 Cable




### STEP 1

- Slide the Heatshrink Sleeve onto the cable (option).
- Slide the Crimp Ferrule onto the cable.
- Strip the cable according to the dimensions as below.




### STEP 2

- Fan the braid.
- Slide the cable into the Main Body.




### STEP 3

- Slide the Crimp Ferrule over the braid.
- Solder the cable's inner conductor.
- Crimp the Crimp Ferrule with crimping tool (3.25mm HEX.).



### STEP 4

- Put the Insulator Spacer into the Main Body.
- Screw the Back Nut onto the Main Body.
- Cut the excess of braid if necessary.
- Slide the Heatshrink Sleeve over the Crimp Ferrule and heatshrink it in place (option).



Note: Dimensions in millimeters (mm).